



Raising the standards in Air Conditioning



*Pocket Quick  
Reference Guide  
On the **TOSHIBA***

*Wired Remote Controllers*

*Accessing the Engineering mode*

*“DN Codes”*

Cool Designs Limited 

Raising standards of design & distribution in the HVAC industry



Gateshead  
0191 5496964



Holmes Chapel  
01925 820000



Glasgow  
01355 234776

[www.cdlweb.info](http://www.cdlweb.info)

## Index

## Page

RBC-AMT32-E, RBC-AMTU31-E, RBC-AMS41-E

3

RBC-AMSU51-E

4

RBC-AMSU52-E, RBC-AWSU52-E

5

RBC-ASCU11-E

6

RBC-ASC11-E

7

RBC-MTSC1, RBC-MTSC2

8

Some useful "DN" Codes

9

Notes

10

Contact Details

12


# Quick Reference Guide

To assist service engineers working on Toshiba air conditioning equipment, there is a large quantity of data available via the wired remote controllers, this data is **NOT** available via an Infra-red remote or a central controller.

Accessing the data is a simple process of entering into the on-board menu of the remote controller.

## RBC-AMT32-E / RBC-AMTU31-E / RBC-AMS41-E


### Accessing the engineering (DN) Codes for the Indoor Unit



Press and hold the **TEST, SET & CL Buttons** simultaneously for 4 seconds.


The Engineering Menu is accessed at item code 10 on the right. The fan and louver of the selected unit will start.

Use the **Temperature ▲▼ Buttons** to navigate to the required code.



When accessing the new 3 figure codes, the third digit will be displayed where the Unit No, (Centre) was displayed, Only accessible using a "U Series Remote Controller"?


To change the unit No., press the left hand "UNIT" button, Unit No flashes three times then returns to the third digit.



Use the **Timer ▲▼ Buttons** to adjust the value from 0000 to 0\*\*\*

Press **SET** to acknowledge the change.


The display will go blank and then flash **SETTING** whilst the system reconfigures.







When **SETTING** stops flashing press **ON/OFF Button** to restart the operation

# RBC-AMSU51-ES

## Accessing the engineering (DN) Codes for the Indoor Unit




1. Press the “[MENU] 2” button to display the “Menu screen”.
2. Press and hold the “[MENU] 2” button and the “[↓]” button at the same time for more than 4 seconds to display the “Field setting menu”
3. Scroll down to page 2, item no. “7 DN Settings” using the “[↓]” button.
4. Press “F2” **Set**
5. Select “Indoor Unit - I. DN”  
Press “F2” **Set**
6. Code (I. DN) 0010 is displayed on the left.  
Using the “[↑]”/ “[↓]”  
Change I. DN from “0010” to “0\*\*\*”  
Press “>” (F2) to highlight “Data” on the right.
7. Change “Data” from “0000” to “0\*\*\*” by pressing the “[↑]”/ “[↓]”
8. Press “[MENU] -2” follow on screen instructions.




# RBC-AMSU/AWSU52-E

## Accessing the engineering (DN) Codes for the Indoor Unit



1. Press the “[MENU]·1” button to display the “Menu screen”.
2. Press and hold the “[MENU]·1” button and the “[↓ ↓]” button at the same time for more than 4 seconds to display the “Field setting menu”
3. Scroll down to page 2, item no. “9 DN Settings” using the “[↓ ↓]” button.
4. Press “Set/Fix - 2”
5. Select “Indoor Unit - I. DN”  
Press “Set/Fix – 2”
6. Press “Select button <” to backlight the code.
7. Code (I. DN) 0010 is displayed on the left.  
Using the “[↑ ↑]/[↓ ↓]”  
Change I. DN from “0010” to “0\*\*\*\*”  
Press “Select button >” to backlight “Data” on the right.
8. Change “Data” from “0000” to “0\*\*\*\*” by pressing the “[↑ ↑]/[↓ ↓]”
9. Press “Set/Fix -2”. “Continued is displayed”
10. To change additional I.DN codes, press “Set/Fix -2”  
Once all codes have been changed press “Return -3” - “⌚ is displayed” whilst changers are fixed.



## RBC-ASCU11-E

### Accessing the engineering (DN) Codes for the Indoor Unit



With power applied but the system **OFF**, i.e. the power light is **NOT** illuminated. Press and hold for 10 seconds the **“Menu -1”** button and the **“Down button -3”**. Once the display changes then press the **“Timer -2”** button.

**The system automatically starts at “DN Code” 10.**


Scroll through the **“DN Codes”** using the **“Up/Down -3,5”** buttons.

To move to **“Data”** (Bottom left display) press the **“Menu -1”** button.

To change the **“Data”** use the **“Up/Down -3,5”** buttons.


To **“Fix”** a change to the **“Data”** press the **“Timer -2”** button.

To end press the **“Power Button”**.



### NOTE.


The new **“UP”** range of VRF indoor units and the new **“U”** series outdoor units (**SMMSu/SHRMa**) utilize a range of new **“DN”** codes, some of which are now three-digit codes, when accessing a three-digit code the last digit is slightly smaller than digits one and two.



**DN Code 103 (3 figure)**

**DN Code 03 (2 figure)**


**RBC-ASU11-E - ONLY**





## Dip Switches.

In the rear of the controller there is a bank of 6 “Dip” switches.



No.	Item	ON	OFF
6	DN Code Set	ON	OFF
5	Press & hold 4 sec	ON	OFF
4	Remote Sensor	ON	OFF
3	TEMP. Set	1°C	0.5°C
2	LCD Back light	OFF	ON
1	Header / Follower	Follower	Header

These allow for certain functions to be enabled or disabled.

- 1) Header/Follower, this allows for more than one remote controller to be connected to a system. (Default setting OFF – Header)
- 2) LCD Back Light, this turns ON/OFF the back-light display. (Default setting OFF, Light ON).
- 3) Temp. Set, this allows for the temperature to be displayed /selected as a whole or a decimal i.e. 21°C Dip switch ON, 21.5°C Dip switch OFF. (Default setting OFF 0.5°C).
- 4) Remote Sensor, this will set the “Return Air – TA” at the remote controller, (Default is OFF – Return Air – TA at the indoor unit.)
- 5) Press and Hold 4 Sec. This will change the operation mode of the ON/OFF switch, the button will need to be pressed and held for 4 seconds or more to turn ON/OFF the system. (Default OFF – No delay.)
- 6) **DN Codes, this allows or restricts access via the buttons on the front of the remote, to the “DN Codes”.** (Default OFF – No access.)

**Note.** Dip switch 6 does **NOT** have the same function as the **RBC-ASCU11-E** remote, on the RBC-AS11-E model, dip switch 6 reduces the light level of the operation indicator light, it does NOT give access to “DN Codes”.

Accessing and adjusting the “DN Codes” are the same as for the **RBC-ASCU11-E**

## RBC-MTSC-1/2

### Accessing the engineering (DN) Codes for the Indoor Unit

To access the configuration menu.


1. Press and hold the bottom **right** corner of the screen, (do not remove your finger) then with a second finger,
2. Press and hold the bottom **left-hand** corner of the screen.
3. Keep pressing the bottom **left** corner of the screen, release your **right-hand** finger from the bottom **right** of the screen, keeping the bottom **left** of the screen pressed.
4. Then tap the bottom **right-hand** corner of the screen **four** times.



If carried out correctly the display screen will change, and the following will be displayed.



### Configuration menu Icons.



**3. DN Code Setting.**  
To change DN code or Data, use the respective UP/DOWN buttons. To enable changes, press the "GREEN" button -9, to EXIT press the "BACK" button -10.

1. General R/C setup		2. User interface setup	
3. DN code editing		4. Appearance	
5. Occupancy strategy		6. Not assigned or used	
7. Diagnostics		8. Model information	
9. Reboot button		10. Back button	

### **DN Code Setting.**

To change "DN code" or "Data", use the respective **UP/DOWN** buttons.

To enable changes, press the "**GREEN**" button -9, to EXIT press the "**BACK**" button -10.



## Some useful DN codes.

**For a full list of “DN Codes” please refer to the service manual for the installed equipment or to one of the” CDL Pocket Handbooks”, available via:**

[www.cdlweb.info](http://www.cdlweb.info)

ITEM	DESCRIPTION	VALUE	DEFAULT																																																						
03	Network address	When under network control. 0099: Unset	0001 to 0064 available 0099																																																						
06	Stratification control	Increases effective return air temperature setting in heating mode (0 to 10K) 0000 to 0010	0002; +2°C Floor type 0000; 0°C																																																						
0d	Auto mode	Enable or disable Auto mode 0000 = available	0001 = unavailable 0000 except SMMSe/u																																																						
0E	SHRMi only	Used when multiple indoor units are served via a single FS box 0000 = normal	0001= multiple units 0000																																																						
0F	Heat Mode	Enable or disable Heat Mode 0000 = available	0001 = unavailable 0000																																																						
10	Indoor unit model	Must be set when replacing indoor printed circuit board	0000: 1-way cassette (s models) 0001: 4-way cassette 0002: 2-way cassette 0003: 1-way cassette (y models) 0004: duct (standard) 0005: slim duct 0006: duct (high static) 0007: ceiling 0008: hi wall 0010: console 0011: concealed floor 0014: 4-way compact cassette (600 x 600) 0013: tall cabinet 0016: fresh air intake 0050: air to air heat exchanger																																																						
11	Indoor unit capacity	0000 will generate a (L09) fault	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th></th> <th>MM</th> <th>RA V</th> <th></th> <th>MM</th> <th>RA V</th> </tr> </thead> <tbody> <tr> <td>0004</td> <td>=005*</td> <td>-</td> <td>0012</td> <td>=027*</td> <td>80*</td> </tr> <tr> <td>0001</td> <td>=007*</td> <td>-</td> <td>0013</td> <td>=030*</td> <td>-</td> </tr> <tr> <td>0003</td> <td>=009*</td> <td>30*</td> <td>0015</td> <td>=036*</td> <td>110*</td> </tr> <tr> <td>0005</td> <td>=012*</td> <td>-</td> <td>0017</td> <td>=048*</td> <td>140*</td> </tr> <tr> <td>0006</td> <td>-</td> <td>40*</td> <td>0018</td> <td>=056*</td> <td>160*</td> </tr> <tr> <td>0007</td> <td>=015*</td> <td>-</td> <td>0021</td> <td>=072*</td> <td>224*</td> </tr> <tr> <td>0009</td> <td>=018*</td> <td>56*</td> <td>0023</td> <td>=096*</td> <td>280*</td> </tr> <tr> <td>0011</td> <td>=024*</td> <td>-</td> <td>-</td> <td>-</td> <td>-</td> </tr> </tbody> </table> <p style="text-align: center;">Air to air heat exchanger Type</p> 0001 = 150m <sup>3</sup> /h 0002 = 250m <sup>3</sup> /h 0003 = 350m <sup>3</sup> /h 0004 = 500m <sup>3</sup> /h 0005 = 650m <sup>3</sup> /h 0006 = 800m <sup>3</sup> /h 0007 = 1000m <sup>3</sup> /h		MM	RA V		MM	RA V	0004	=005*	-	0012	=027*	80*	0001	=007*	-	0013	=030*	-	0003	=009*	30*	0015	=036*	110*	0005	=012*	-	0017	=048*	140*	0006	-	40*	0018	=056*	160*	0007	=015*	-	0021	=072*	224*	0009	=018*	56*	0023	=096*	280*	0011	=024*	-	-	-	-
	MM	RA V		MM	RA V																																																				
0004	=005*	-	0012	=027*	80*																																																				
0001	=007*	-	0013	=030*	-																																																				
0003	=009*	30*	0015	=036*	110*																																																				
0005	=012*	-	0017	=048*	140*																																																				
0006	-	40*	0018	=056*	160*																																																				
0007	=015*	-	0021	=072*	224*																																																				
0009	=018*	56*	0023	=096*	280*																																																				
0011	=024*	-	-	-	-																																																				
12	System number	DI/SDI indoor and outdoor units are automatically addressed, this value may be set manually but it must be done via the wired controller – on an individual basis. Settings are 0001 to 0030	0001 to 0064 No.30-unit TCC-Link 0001 to 0128 No.128 unit – TCU2-Link 00Un Unfixed “U” series remote. 0099 Unfixed “Non-U” series remote 00Un / 0099																																																						
13	Indoor unit number	Indoor units connected to a common outdoor unit (e.g. twinned indoor units) will have the same system number - settings are 0001 to 0064. Automatically allocated – but may be manually overridden.	0001 to 0064 No.30-unit TCC-Link 0001 to 0128 No.128 unit – TCU2-Link 00Un Unfixed “U” series remote. 0099 Unfixed “Non-U” series remote 00Un / 0099																																																						
14	Group master/slave	Allows selection of master indoor unit within group. Automatically allocated but may be manually overridden.	0000: single indoor unit 0001: group master 0002: group slave 00Un / 0099																																																						
16	Indoor Fan	Indoor fan speed selection. Binary addition.	0015 = all speeds available 1 = auto; 2 = low; 4 = medium; 8 = high 0015 except high static 0008																																																						
1E	Dead band - auto	Changeover sensitivity in automatic mode. (1 to 10 k adjustable)	0000: 0 K 0010: 10 K 0003																																																						
1F	Max. Setting	Cooling mode maximum temperature setting (18 – 29°C)	0018 = 18°C 0020 = 20°C 0029 = 29°C 29 ° C																																																						
20	Min. Setting	Cooling mode minimum temperature setting (18 – 29°C)	0018 = 18°C 0020 = 20°C 0029 = 29°C 18 ° C																																																						
21	Max. Setting	Heating mode maximum temperature setting (18 – 29°C)	0018 = 18°C 0020 = 20°C 0029 = 29°C 29 ° C																																																						
22	Min. Setting	Heating mode minimum temperature setting (18 – 29°C)	0018 = 18°C 0020 = 20°C 0029 = 29°C 18 ° C																																																						
23	Max. Setting	Dry mode maximum temperature setting (18 – 29°C)	0018 = 18°C 0020 = 20°C 0029 = 29°C 29 ° C																																																						
24	Min. Setting	Dry mode minimum temperature setting (18 – 29°C)	0018 = 18°C 0020 = 20°C 0029 = 29°C 18 ° C																																																						
25	Max. Setting	Auto mode maximum temperature setting (18 – 29°C)	0018 = 18°C 0020 = 20°C 0029 = 29°C 29 ° C																																																						
26	Min. Setting	Auto mode minimum temperature setting (18 – 29°C)	0018 = 18°C 0020 = 20°C 0029 = 29°C 18 ° C																																																						
28	Auto restart	Enable or disable 0000: disabled	0001: enabled 0000																																																						
2d	Modes available	Binary addition of modes available. 0015= all modes 1 = fan; 2 = cool; 4 = dry 8 = heat	0015																																																						
32	TA Sensor Location	Return air/room sensor or in local controller 0000: return air sensor (Unit)	0001: Remote Controller 0000																																																						
103	Remote Controller	VRF IDU “U” Series Local remote controller used or not used 0000: Use	0001: Do not use 0000																																																						

NOTES

NOTES

Contact details:

# Cool Designs Ltd

## Technical Support

**07590 775510 / 07706 293028 / 07732 494822**

**Monday – Friday 07.30 to 19.30**

**Email: [support@cooldesignsltd.co.uk](mailto:support@cooldesignsltd.co.uk)**

**Web site: [www.cdlweb.info](http://www.cdlweb.info)**

**TOSHIBA Air Conditioning**

**24/7 technical support**

**0870 843 0333 (Option 7)**



**[Try our on-line training videos on YouTube.](#)**

Cool Designs Ltd reserves the right to change the product specifications, data, and images without notice.